

Multisport

Time out request system





(non contractual picture)

Composition

2 Wireless remote controls

1 receiver integrated to the main control console or the portable W-Top Operating instructions

Description

Use : Indoor/Outdoor Transmission : Radio up to 30m

Function

Each coach has its own remote control.

The coach requests a time-out, by pressing the button of the remote control:

- The timer stops
- The buzzer sounds
- The time-out timer starts
- The time-out timer is displayed on the scoreboard
- Green dots on the scoreboard indicate the number of used time outs for each team.

452 TIME OUT REQUEST SYSTEM MULTISPORT_GB_A